Ez One Shot®

BARCODE SCANNER USER'S MANUAL

DEFAULT

Version: 2013.1

CONTENTS

GENERAL

Table of contents	1
Preface, Ez Troubleshooting	2-3
Cloning Mode	4-5
How to fix the scanner to the terminal	6-7
How to change a cable	7
How to set up the parameter	8

SETTING GROUP(GROUP1~14)

1 Interfaces selection, Computer type, Default,	Q
2 Reading Mode	
Bi-color Setting	
Advanced Autosensing Setting	12
Advanced Autosensing and Idle Mode Setting.	13
Wireless Scanner Setting	14-26
3 Check Version, Beep tone, Terminator	27
4 Send Data Length, Preamble, Postamble	28
5 Accuracy adjustment	29
6 Code ID, Label Type Positive/Negative	30
7 Symbologies Code Identifier	31
8~9 Set Code ID, Customer Configuration	32-33
10 Delay between block and character	34
11 Keyboard layout, Caplock Mode, Numeric Ke	y35
12 RS232: Baud rate, Data bits, Parity	36
13 RS232: Stop bit, Handshaking, ACK/NAK,	
Flow Control, BCC	37
14 Wand Emulation parameter setting	

(SYMBOLOGY FORMATTING(GROUP15~32))

15~17 Enable/Disable Barcode Symbology	39-41
17 China postcode(Toshiba code)	41
18 MSI code, UK Plessey code	43
19 Code 93, Telepen, IATA	45
20 Interleaved 2 of 5, Code 11	
21 Industrial 2 of 5, Matrix 2 of 5	
22 Codabar	51
23 ABC Codabar, CX Codabar	53
24 Codabar Coupling	54
25 Code 39 (Full ASCII/Standard), Code 32	55
26 UPC-E	57
27 UPC-E(0)&(1), UPC-E EXPAND	
28 UPC-A	59
29 EAN-8	60
30 EAN-13, ISSN, ISBN, ISMN	61
31 EAN/UCC 128, Code 128, PDF417	62
32 DataBar(RSS) Stacked, Limited, Expanded	63
FULL ASCII(CODE39)TABLE, FUNCTIO	N
KEY TABLE(GROUP33~47)	
33~41 Full ASCII table(Code 39)	
42~44 Function Key table(Code 39) for PC-AT	73-75
45~47 Trouble Shooting	76-78
APPENDIX	
Appendix 1 Default table	79-82
Appendix 2 Cable Pin Assignment	83-84
Appendix 3 Barcode test chart	85-86

No	Kind of Troubles	Symptoms	Solutions
1	Computer Type (Group 1)	Scanner seems to be performing as usual, but no data is being output.	 Unplug the cable from the host computer. Plug the cable back into the host computer. Set the scanner to the exact computer type immediately.
2	Interfaces Selection (Group 1)	The scanner does not scan when the trigger is depressed.	 Unplug the cable from the host computer. Plug the cable back into the host computer. Set the scanner to the correct interface. The cable needs to match the interface.
3	Setting Procedure have not completed (Setting Need Triple Shot scanning) Group - 4, 5, 8, 9, 17, 18, 19, 20, 22, 23, 25, 31	The scanner does not output data and beeps three times at every scan. This symptom indicates that a three-scan setting is not yet completed. Some settings take three scans to complete, they are: 1. Preamble, Postamble (Group4) 2. Accuracy Adjustment (Group5) 3. Customer ID Configuration (Group 8 & 9) 4. Min/Max Length (Group 17, 18, 19, 20, 21, 22, 25) 5. ABC Codabar (Group 22 & 23) 6. CX-Codabar (Group 22 & 23) 7. Coupling Codabar (Group 22 & 23) 8. EAN 128 (Group 31)	 Follow the procedures for these settings at the appropriate pages. The scanner will beep three times for an incomplete setting. Scan RESET to try a setting again.
4	Limitation of length of the bar code	The scanner is reading correctly, except for certain bar codes of a certain length.	Reset the Min/Max setting for the bar code symbology affected.
5	Setup Code Disabled	When scanning the Default barcode, the scanner is not reset to Default but output data ".A001\$".	Scan SETUP CODE ON(Group 1) to enable all setup codes.
6	RS232 Protocol Communication setting problem	The scanner appears to be working in the RS-232 interface, but no data is output.	Ensure the correct RS-232 communication parameters have been set: Baud Rate, Handshaking, Stop Bits, Data Bits, and Parity. These settings must be the same for both the scanner and the host.

CLONING MODE

WHAT IS CLONING MODE?

CLONING duplicates a scanners settings in other scanners. It can save time when a number of scanners must be programmed to the same settings.

HOW SHOULD CLONING WORK?

- 1. Using this guide, make all the necessary settings for one wand.
- 2. Scan the CLONING MODE bar code shown below.
- When CLONING MODE is scanned, all setup parameters will be converted to alphanumeric characters and shown on the monitor.
- 4. Using a bar code printer, print out all the setup parameters as Code 39 bar code labels.
- Scan the printed labels sequentially with each wand to be programmed.



.A018\$(Cloning Mode on PC/AT) - you can clone the settings to a PC/AT regardless of the kind of device chosen on the scanner.

NOTES:

- 1. All cloning strings are upper case.
- All cloning strings printed on labels should be the same as those on the monitor sequentially from first to last.
- 3. Cloning mode works in Word Note Pad only.
- Never edit the data on the first row (.A017\$). It is an entry command for cloning.
- The cloning string's length can be adjusted by combining multiple strings into one, or by breaking one string into multiple strings starting from the second row after "...". Length must be in sequences of four, such as 4, 8, 12, 16, 20 (MAX).
- 6. Be sure to print the dots exactly where they are shown on the monitor.

FORMAT OF CLONING

* Format of Cloning:

1st row >>> ".AŬ17\$" (never edit any data of the first row) 2nd row >>> "...XXXX" you can adjust the String's Length starting from the dots "..." forward. The length of the string should be in 4, 8, 12, 16 or 20 (MAX)digits. 3rd row ~ so on >>> XXXX End row - A dot ".." Is the ending of cloning.

XXXX Stands for any string

EXAMPLE :

- 1. PROJECT ASSIGNMENTS:
- 1.1. Beep tone: BEEP LOW -- HIGH. 1.2. Capslock Mode: CAPSLOCK ON. 1.3. Reading Mode: CONTINUOUS AUTO OFF.

- 2. SETTING PROCEDURE: 2.1. Scan BEEP LOW -- HIGH (GROUP 3). 2.2. Scan CAPSLOCK ON (GROUP 11). 2.3. Scan CONTINUOUS AUTO OFF (GROUP2).
- All parameters will be converted to alphanumeric characters and shown on the monitor.



Print the results shown on the monitor as bar codes with a bar code printer. The bar codes should be in the Code 39 symbology.





5. Scan these labels with any of the wands that must be programmed with the same settings as the first wand. Be sure to scan from the first row to the second and so on sequentially, top to bottom.

CORRECT SETTING

.A017\$ 0604 5A02 5F04	4 4 4 . (Dot)	.A017\$ 06045A02 5F04.	12 4+.(Dot)
	WRONG	SETTING	
.A017\$ 	««	Wrong Setting: The consists of 4 Dots, lo beginning of second break the "" into m	string "" cated at the row; do not ultiple strings.
.A017\$ 06045 A025F04	9 x 7 x} . (Dot)′	 Wrong Setting: The second and third row length requirements, be in length of four d 	string lengths of the do not match the because rows should igits.
.A017\$ 0604 5A02 5F04.	X • 4 ~ 4 ~ 4 + . (Dot)	Wrong Setting beca "" after .A017\$: The .A017\$ is a FIXE enter setup procedur parameter. Never ad data from the FIRST	ED parameter to ED parameter to e. It is an unchangeable Id, delete or rearrange f row.

HOW TO CONNECT THE SCANNER TO THE **HOST TERMINAL: Handheld Barcode Scanner**

KEYBOARD WEDGE INTERFACE

- 1. Power down the host computer.
- 2. Disconnect the keyboard cable from the computer.
- 3. Connect the "Y " cable between the keyboard and the scanner and computer.
- 4. Restart the computer.
- 5. The scanner will beep.
- 6. Set the scanner to KEYBOARD interface by referring to GROUP 1 (Interfaces Selection)
- 7. Scanner will beep to confirm the setting.
- 8. Scan a bar code to confirm that data shows on the monitor.



RS-232 INTERFACE

- 1. Power down the host computer.
- 2. Disconnect the RS-232 cable between the scanner and computer.
- 3. Connect the power adaptor to the cable.
- Restart the computer,
- 5. Plug the power adaptor into a power outlet.
- The scanner will beep.
 Set the scanner to RS-232 interface by referring to GROUP 1 (Interfaces Selection).
- 8. Set RS-232 protocol: Baud Rate, Stop Bits, Handshaking, Data Bits and Parity.
- 9. Scan a bar code to confirm that data shows on the monitor.

- 1. Before plugging the power adaptor into the scanner, be sure the voltage, power consumption, and inner and outer DC characteristics are correct to avoid serious damage to the scanner and/or the computer.
- 2. Make sure the protocol communication settings of the scanner (such as baud rate, data bits, etc.) match those of the host computer. Otherwise, no data will be transmitted.



USB INTERFACE

The USB Interface supported is compatible with Apple MAC series, later PCs and Windows 98, 2000, Me and XP, Vista.

- 1. Connect the USB cable between the scanner and the computer.
- 2. The scanner will beep.
- The scanner will detect the USB driver automatically. (The first time the scanner is connected via the USB port, follow the appropriate instructions for the host computer.)
- Set the scanner to KEYBOARD/USB interface by referring to GROUP-1 (Interfaces Selection)
- 5. Scanner will beep to confirm the setting.
- 6. Scan a bar code to confirm that data shows on the monitor.



HOW TO CHANGE A CABLE

The scanners are designed to switch easily between interface options. To switch from one interface to another, the appropriate cable must be installed. To change a cabl, simply follow these steps:

- 1. To release the cable, insert a pin or straightened paper clip into the hole at the base of the scanner where the cable is connected.
- 2. Remove the cable from the scanner.
- 3. Plug in the new cable.

After changing to a new cable, be sure to reset the interface setting as appropriate (including parameter settings for the RS-232 interface).



HOW TO SET PARAMETERS

How do you program a scanner with this user's guide?

- 1. Use the scanner to scan at the bar code representing the function/ parameter you want to set.
- 2. When you hear two beeps, the new settings have been defined or updated into the memory processor.

Default parameters are indicated in bold type and underlined characters. The character font is ARIAL BLACK. CD = Check Digit. CDV = Check Digit Verification.

Most settings require only a single bar code, but a few need several different bar codes to be scanned in order to completely define a setting. They are:



-----SETTING BAR CODE

Preamble / Postamble (maximum 16 digits)

Step 1: Scan CLR PRE/POSTAMBLE.

Step 2: Scan PREAMBLE or POSTAMBLE Step 3: Scan any alphanumeric from Full ASCII Table in Group 33-44

Step 4: Scan PREAMBLE or POSTAMBLE.

Min Length / Max Length

Step 1: Scan MIN LENGTH or MAX LENGTH. Step 2: Scan two digits from Group 41 or Full ASCII numeric table in Appendix Step 3: Scan MIN LENGTH or MAX LENGTH.

Accuracy Adjustment

Step 1: Scan ACCURACY ADJUSTMENT.

Step 2: Scan one digit from GROUP 5

Step 3: Scan ACCURACY ADJUSTMENT.

Set Code ID (Example: Code 39)

Step 1: Scan CODE 39 SET ID from Group 8

Step 2: Scan either one or two alphanumerics (maximum 2 digits) from Full ASCII table in Group 35-41

Step 3: Scan CODE 39 SET ID from Group 8

Set A Data - (CX-Codabar, ABC Codabar, Codabar Coupling). Step 1: Scan SET INSERT DATA.

Step 2: Scan one alphanumeric character from Full ASCII Table in Group 35-41 Step 3: Scan SET INSERT DATA.

NOTES:

1. The scanner will beep three times as a reminder that a setting is not yet complete.

2. If you make a mistake, forget a step, etc., scan RESET to start again.



INTERFACES SELECTION, COMPUTER TYPE, DEFAULT, SETUP CODE

DEFAULT

COMPUTER TYPE





PC-AT



SYMPTOMS	SOLUTION
Scanner seems to be performing as usual, but no data is being output.	 Unplug the cable from the host computer. Plug the cable back into the host computer. Set the scanner to the exact computer type immediately.

Caution: Please ensure the correct computer type is set when the scanner is attached to a new host computer. If set to Notebook, the scanner will operate with no external keyboard.







SYMPTOMS	SOLUTION
The wand does not scan/ The scanner does not scan when the trigger is depressed.	 Unplug the cable from the host computer. Plug the cable back into the host computer. Set the wand to the correct interface. The cable needs to match the interface.

Caution: This scanner is designed to switch easily between interface options. To switch from one interface to another, the appropriate cable must be installed. After changing to a new cable, be sure to reset the interface setting as appropriate.

SETUP CODE READ



Caution: Scanning SETUP CODE OFF will turn the scanner into unprogrammable state and the scanner will not react to any setup code.

READING MODE SETTING







- * LED is always on.
- * The trigger does not function in Continuous Mode.
- * The LED is on steady if a bar code is close to the scanner, but starts flashing if no bar code is detected after 60 seconds.
- * The trigger does not function in Flash Mode.
- * The LED will light when the trigger is pressed.
- * The LED will go off when the trigger is released.





*AUTO SENSING MODE(CCD)

*AUTO SENSING MODE(Laser)

F007\$

F010\$

- * The LED is always on when the trigger is pressed.
- * The LED will go off if no bar code has been detected after 60 seconds.
- * This function works like Trigger Mode, but the scanner beeps to indicate a good read.
- * If Auto-Sensing Mode(CCD) is on, the LED will go off if no bar code is detected after Deactivation Time elapses.(The default is 3 sec.)
- * The LED lights automatically when a BAR CODE is detected.
- * If Auto-Sensing Mode(CCD) is on, the Magnetic Switch and Blue LED will be activated at the same time.
- * If Auto-Sensing Mode(Laser) is on, the LED will go off if no barcode is detected after Deactivation Time elapses.(The default is 3 sec.)
- * The laser emits automatically when an OBJECT is detected.
- * If Auto-Sensing Mode(Laser) is on, the Magnetic Switch will be activated.

- 1. To extend the scanner's life, keep the scanner set to Trigger Mode or Continuous Auto Off Mode.
- 2. The LED indicator will glow for GOOD READ.
- For advanced settings of Auto-Sensing Mode(such as Deactivation Time, Magnetic Switch and Blue LED) please refer to the next pages.

BI-COLOR LIGHT SOURCE SETTINGS

(The following settings are supported by Bi-Color models)

CYCLE MODE











NOTES:

- 1. Illumination color will switch back and forth from one to another when good read does not occur.
- 2. Illumination color will remain as the one used at the last good read.

SINGLE MODE







NOTES:

1. Illumination color will remain single.

ADVANCED AUTO-SENSING MODE SETTINGS

(The following settings are available after the activation of Auto-Sensing Mode)

MAGNETIC SWITCH (CCD & LASER SCANNERS)





NOTES:

- 1. The Magnetic Switch is automatically activated when Auto-Sensing Mode is on.
- 2. To enable Magnetic Switch, the scanner should be paired with an Autosense Stand to perform Auto-Sensing function.
- 3. When Magnetic Switch is disabled, the scanner will perform Auto-Sensing function without Autosense Stand.

GREEN LED/ SUPPLEMENT LIGHT (CCD SCANNER ONLY)





- 1. The green LED is automatically activated when Auto-Sensing Mode is on.
- Green LED serves as Supplement Light for a CCD scanner in order to enhance the sensitivity of scanner in Auto-Sensing Mode.

ADVANCED AUTO-SENSING MODE SETTINGS

(The following settings are available after the activation of Auto-Sensing Mode)



DEACTIVATION TIME (CCD & LASER SCANNERS)

NOTES:

- 1. The default of Deactivation Time is 3 Sec.
- Deactivation Time is the time interval between the last scan and the automatic deactivation of LED or Laser light in Auto-Sensing Mode.
- You can set the Deactivation Time value by the following three steps:

Step 1: scan Deactivation Time

Step 2: scan two digits(Limit Range: 01 ~ 30sec.) from the Full ASCII numeric table.





SAME CODE INTERVAL (LASER SCANNER ONLY)

NOTES:

- 1. The default of Same Code Interval is 30 Sec.
- 2. Same Code Interval is the time interval between two consecutive scans on the SAME bar code in Auto-Sensing Mode.
- You can set the value of Same Code Interval by the following three steps:
- Step 1: scan Same Code Interval
- Step 2: scan two digits(Limit Range: 03 ~ 60sec.)from the Full ASCII numeric table.
- Step 3: scan Same Code Interval

IDLE MODE SETTING

IDLE MODE



Pre-Idle Time





- 1. Idle Mode is only supported by certain models.
- When Idle Mode is on, the scanner will enter idle state to save power after a period of inactivity, or Pre-Idle Time(the default is 1 min).
- 3. You can set the value of Pre-Idle Time by the following four steps:
- Step 1: scan Idle Mode On
- Step 2: scan Pre-Idle Time
- Step 3: scan one digits(Limit Range: 1~9 Min.)from the Full ASCII numeric table.
- Step 4: scan Pre-Idle Time

WIRELESS SCANNER SETTINGS

LED & BEEPER INDICATION

	Status	Blue/Green LED	Red LED	Beeper	Remark
	Initializing/ Power-up		Solid for 2 sec	1 long beep	
	Successful Barcode Scan	1 Flash		1 beep	
	Successful Connection	2 Flashes		2 beeps	
	Reads Configuration Barcode			2 short beeps	
	Data Temporarily Stored	1 Flash		High-Low beeps	See Batch Mode
Scanner	Data Permanently Stored	1 Flash		Low-High beeps	See Memory Mode
	Wireless Disconnection	Solid for 2 sec		3 beeps	
	Unsuccessful Pincode Setup	Flashing		3 short beeps	Scan Pincode Stop and retry
	Barcode Scan w/o Connection	Flashing		3 short beeps	
	Low Power		Flashing	5 beeps	
	Barcode Scan w/o Connection	Flashing		Several short beeps	
	Power Off or Standby				See Power Off Timeout
	Status	Blue LED	Red LED	Green LED	Remark
	Successful Connection	Solid			
Cradle	Charging		Solid	Flashing	Power adaptor needed
	Full Charge			Flashing	4 hours to fully charge

WIRELESS SCANNER SETTINGS

CONNECTION OPTIONS



BT mode - HID plug & play

- 1. Connect the cradle to the host PC.
- 2. Scan [DISCONNECT]
- Scan [BT mode HiD plug & play], and the scanner will emit 8 beeps.
- 4. Scan the Host Address barcode on the cradle's bottom.
- 5. The scanner will beep twice and cradle's blue indicator LED will stay on to verify a successful connection.

*Note: Only supported by model with charging cradle.





- 1. Press the trigger for 1 second to activate the scanner.
- 2. Scan [DISCONNECT]
- 3. Scan [BT mode HID non-pincode]; the scanner will emit 8 beeps.
- 4. Select "Wireless Scanner" from discovered device list.
- 5. For PC, please click "Pair without using a code"
- 6. The scanner will beep twice to verify the connection.

*Note: In this mode, the scanner is recognized by the host as a mouse (pointing device). If your host fails to find it, please try [**BT mode - HID**] instead.





- 1. Press the trigger for 1 second to activate the scanner.
- 2. Scan [DISCONNECT]
- 3. Scan [BT mode SPP]; the scanner will emit 8 beeps.
- 4. Select "Wireless Scanner" from discovered device list.
- 5. For PC, please click "Enter the device's pairing code".
- 6. Enter "1234" from the host.
- Open serial communication software with com port (see Device Manager) properly set up.
- 8. The scanner will beep twice to verify the connection.





- 1. Press the trigger for 1 second to activate the scanner.
- 2. Scan [DISCONNECT]
- 3. Scan [BT mode HID]; the scanner will emit 8 beeps.
- 4. Select "Wireless Scanner" from discovered device list.
- 5. For PC, please click "Create a pairing code for me"
- 6. The Bluetooth application may prompt you to scan a pincode.
- 7. Follow the steps in **PINCODE SETUP** section the on next page.
- 8. The scanner will beep twice to verify the connection.



Disconnect

WIRELESS SCANNER SETTINGS

PINCODE SETUP

STEP 1

Pincode Start



STEP 2

Scan numeric barcodes (see **NUMERIC BARCODES** below) based on the pincode generated by the Bluetooth application.

NUMERIC BARCODES



WIRELESS SCANNER SETTINGS

SET BLUETOOTH DEVICE ID

To customize your own Bluetooth device name for the wireless scanner, please follow below steps:

STEP 1



STEP 2

Set Wireless ID



STEP 3

Scan 7 alphanumeric characters from Full ASCII Table (GROUP 35-41)

STEP 4

Set Wireless ID



STEP 5

Scan a desired BT mode in **Connection Option** (GROUP 2.6) to complete the configuration.

*Note:

- If you have connected the scanner with the host BEFORE customizing your Bluetooth device name, please remove the device and create a new connection to make sure device name is refreshed. For PC, it is recommended to restart the Bluetooth adaptor in order to refresh device name.
- 2. At Step 3, the scanner will beep three times as an alert that more than 7 characters are entered.
- 3. To reset the Bluetooth device name to default ("Wireless Scanner"), please simply do Step 1 & Step 5, skipping Step 2 to Step 4.

WIRELESS SCANNER SETTINGS

POWER OFF TIMEOUT

The timeout before automatic power-off to save battery power.



WIRELESS SCANNER SETTINGS

iOS (Apple)

Getting Connected

Please pair with the scanner via [BT mode - HID]. (GROUP 2.6)

Getting Connected without Pincode



ENABLE SSP

Secure Simple Pairing (SSP), supported by Bluetooth 2.1 or above, allows you to pair with iOS without pincode. Please scan [Enable SSP] above before entering the pairing procedure of [BT mode - HID]. (GROUP 2.6)



ENABLE IOS HOTKEY

DISABLE IOS HOTKEY

After enabling iOS Hotkey(disabled by default), you may simply <u>double-click the trigger</u> to toggle the iPhone/iPad Touch Keyboard.

Getting Connected

Android

To get connected to Android, please follow the instruction in [**BT mode - HID**]. (GROUP 2.6)

Touch Keyboard

While connected with the scanner, the Touch Keyboard on the Android smartphone or tablet might disappear. To resolve this issue, please change settings on Android device with below steps:

- 1. Enter "Settings"
- 2. Enter "Language & input"
- 3. In Keyboard & input window, tap "Default" to continue.
- 4. Turn off "Hardware Physical keyboard", and the Touch
 - Keyboard will function properly again.

Choose input method	
Hardware Physical keyboard	OFF
English (US) ASUS Keyboard	•
English (US) Android keyboard (AOSP)	O.
BluetoothConnect	0
Set up input metho	ds

WIRELESS SCANNER SETTINGS

LINK QUALITY

ENABLE

DISABLE



When enabled, Link Quality ensures a more secure data transmission from the scanner to the cradle/host. However the distance of data transmission will decrease.

BATCH MODE



When out of range, the scanner will temporarily keep scanned data in its memory buffer(2K RAM) until the buffer is full. The scanner will send all stored data back to the host after getting in range.

*Note:

 Batch Mode will not function when Memory Mode is enabled, or no connection is made beforehand.
 It is recommanded to turn [LINK QUALITY] <u>OFF</u> in order to let Batch Mode function properly.

WIRELESS SCANNER SETTINGS

SPP MASTER MODE

First, please generate one configuration barcode for the target SPP slave device in below methods: 1. The barcode must be Code 39 2. Barcode data format: LTB + Target MAC address

For example, the target SPP slave device's MAC address is 001583522C3B.

Please encode: *LTB001583522C3B* in Code39 barcode.

Then, follow below steps to create connection:

STEP 1



STEP 2





*Note: Please skip this step if the target SPP slave device does not support non-pincode connection.

STEP 3



WIRELESS SCANNER SETTINGS

SET SPP PINCODE

By default, the SPP pincode for the scanner is "1234". You may customize this pincode with below steps:

Set SPP Pincode



STEP 2

STEP 1

Scan numeric barcodes (see **NUMERIC BARCODES** below) Up to 8 numbers can be set as SPP pincode.

NUMERIC BARCODES



STEP 4

Scan a desired BT mode in **Connection Option** (GROUP 2.6) to complete the configuration.

WIRELESS SCANNER SETTINGS

SPP REMOTE CONTROL

There are two ways for the scanner to reply to the host whether it is well connected:

Command Response

Host sends:	CR,LF,{,A,L,},CR,LF	(8 bytes)
Scanner replys:	O,K,CR,LF	(4 bytes)

Beeper Response

Host sends:	CR,LF,{,M,1,},CR,LF	(8 bytes)
Scanner reacts:	a short beep	

SHUT DOWN

This configuration barcode will shut down the scanner immediately and reserve the pairing record.



SHUT DOWN

DISCONNECTION





DISCONNECT (Clear Pairing Record)



WIRELESS SCANNER SETTINGS



For memory version only

ENABLE MEMORY

DISABLE MEMORY

Once enabled, the scanner will stop sending data via Bluetooth and start storing data into the internal flash disk (2MB)

Delete Last Record/ Clear All Record



DELETE LAST RECORD

CLEAR ALL RECORD

OUTPUT DATA 🔳

For memory version only



You may output data ONLY when memory is enabled (GROUP 2.15)

Data Output Method

WIRELESS



USB-VCP

To output stored data via Wireless, please do the following:

- 1. Scan [WIRELESS]
- 2. Scan [OUTPUT DATA]

To output stored data via USB-VCP, please do the following:

- 1. Install VCP driver (available on CD)
- 2. Connect the scanner & host with USB cable
- 3. Scan [USB-VCP]
- 4. Save data as *.csv by "Covert to CSV.exe" (available on CD)

WIRELESS SCANNER SETTINGS

DATA FORMAT 🔳



For memory version only

DATA FORMAT

The default Data Format is <Item No.>, <Date>, <Time>, <Barcode Data> below are items and their setup codes:

Code	Item	Code	Item
1	ltem No.	3	Time
2	Date	4	Barcode Data

Example:

To change Data Format to <Item No.>, <Barcode Data>, <Date>, <Time> 1. Scan [Data Format]

- 2. Scan [1], [4], [2], [3] from Group 41.
- 3. Scan [Data Format]



FIELD SEPARATOR

Default is comma (,) . You may replace it with any alphanumeric characters from the full ASCII table in User's Manual (on CD).

Example: To change Field Separator to Semicolon (;)

- 1. Scan [Field Separator]
- 2. Scan [;] from the full ASCII table(Group 33-41)
- 3. Scan [Field Separator]

DATE & TIME SETUP 🔳

SET DATE

SFT TIMF

For memory version only



Example: To set Date to 2012-08-01 (Year-Month-Day):

- 1. Scan [Set Date]
- 2. Scan [1], [2], [0], [8], [0], [1] from Group 41.
- 3. Scan [Set Date]



Example: To set Time to 08:10:30 am (Hr:Min:Sec)

- 1. Scan [Set Time]
- 2. Scan [0], [8], [1], [0], [3], [0] from Group 41.
- 3. Scan [Set Time]

* To avoid Time and Date being reset to factory default due to running out of battery, please fully charge the scanner for at least 3 hours before use.

WIRELESS SCANNER SETTINGS

DATE FORMAT 🔳

For memory version only



DATE FORMAT

The default Date Format is DD/MM/YYYY (Code = 09), below is full list of available formats and their setup codes:

Code	Format	Code	Format
01	DD-MM-YYYY	09	DD/MM/YYYY
02	MM-DD-YYYY	10	MM/DD/YYYY
03	DD-MM-YY	11	DD/MM/YY
04	MM-DD-YY	12	MM/DD/YY
05	YYYY-MM-DD	13	YYYY/MM/DD
06	YY-MM-DD	14	YY/MM/DD
07	DD-MM	15	DD/MM
08	MM-DD	16	MM/DD

Example:

- To set Date Format to MM/DD/YY (Code = 12)
- 1. Scan [Date Format]
- 2. Scan [1], [2] from Group 41.
- 3. Scan [Date Format]

TIME FORMAT 🔳

TIME FORMAT

For memory version only



The default Time Format is HH:MM:SS (Code = 01), below are available formats and their setup codes:

Code	Format	Code	Format
01	HH:MM:SS	02	HH:MM

Example:

To set Time Format to HH:MM (Code = 02)

1. Scan [Time Format]

2. Scan [0], [2] from Group 41.

3. Scan [TimeFormat]

CHECK VERSION, BEEP TONE, TERMINATOR



- 1. For the Keyboard Wedge interface the default terminator is CR.
- 2. For the USB interface the default terminator is CR.
- 3. For the RS232 interface the default terminator is CR+LF.

SEND DATA LENGTH, PREAMBLE & POSTAMBLE.



PREAMBLE & POSTAMBLE (PREFIX AND SUFFIX)





POSTAMBLE (16)

EXAMPLE:

Set PREAMBLE String as " ## " POSTAMBLE String as " \$\$ "

SETTING PROCEDURE:

STEP 1 : Scan : CLEAR PRE/ POSTAMBLE. STEP 2 : Scan : PREAMBLE. STEP 3 : Scan : "# " twice from FULL ASCII Table. STEP 4 : Scan : PREAMBLE. STEP 5 : Scan : POSTAMBLE. STEP 6 : Scan : \$ " twice from FULL ASCII Table. STEP 7 : Scan : POSTAMBLE.

FORMAT:

{Preamble}{Code ID}{Bar Code}{Postamble}

- 1. A PREAMBLE is a string of up to 16 characters added to the beginning of a scanned barcode.
- 2. A POSTAMBLE is a string of up to 16 characters added to the end of a scanned barcode.
- 3. Default value for both: None.



ACCURACY ADJUSTMENT



Accuracy Adjustment assures a more reliable decoded output. Enabling the feature and setting a number from 1 to 9 subjects the decoded output a higher standard of accuracy. The higher the number, the greater the accuracy.

SETTING PROCEDURE: 1. Scan ACCURACY ADJUSTMENT. 2. Scan one digit (1~9) from barcode menu above. 3. Scan ACCURACY ADJUSTMENT. P023\$ RESET

- The scanner will beep three times as reminder that a setting is not yet complete.
- If you make a mistake, forget a step, etc., scan RESET to start again.

LABEL TYPE POSITIVE / NEGATIVE, ENABLE AND DISABLE CODE ID

LABEL TYPE POSITIVE / NEGATIVE





(POSITIVE & NEGATIVE ENABLE)









DISABLE CODE ID



NOTES:

- Only ONE code ID will be sent.
 The code ID is located at the position before the bar code data and after the preamble.

EXAMPLE :

- 1.Preamble 145287,
- 2.Code ID: enable AIM ID,
- 3.Bar code symbologies : EAN 13+5

145287]E0	4563987123453	12411
Preamble 145287	CODE ID AIM ID :]EC	BARCODE / D EAN 13 +5	ATA
OUTPUT	: 145287]E04	563987123453124	11

SYMBOLOGIES	CODE	ID IDENTIFIER,	SET ID
-------------	------	----------------	--------

SYMBOLOGIES CODE ID IDENTIFIER					
Symbologias	Factory	AIM ID	Sumbologies	Factory	AIM ID
symbologies	ID	(new)	Symbologies	ID	(new)
EAN 128	Т]C1	MSI	0]M0
Code 128	K]C0	MSI(MOD 10 / CDV & not send CD)	0]M1
EAN8(+2/+5 OFF)]E4	Code 32	В]X0
EAN8(+2 ON)	S]E4	Codabar]F0
EAN8(+5 ON)]E4	Codabar(ABC Codabar)	N]F1
UPC-E(+2/+5 OFF)]E0	Codabar(CDV & Send CD)	IN]F2
UPC-E(+2 ON)	Е]E3	Codabar(CDV & not send CD)]F4
UPC-E(+5 ON)]E3	UK Plessey	Р]P0
UPC-A(+2/+5 OFF)]E0	Matrix 2 of 5	Y]X0
UPC-A(+2 ON)	А]E3	Full ASCII Code 39(disable CDV)]A4
UPC-A(+5 ON)]E3	Full ASCII Code 39(CDV & send CD)	D]A5
EAN-13(+2/+5 OFF)]E0	Full ASCII Code 39(CDV & not send CD)]A7
EAN-13(+2 ON)	F]E3	Standard Code 39(disable CDV)]A0
EAN-13(+5 ON)]E3	Standard Code 39(CDV & send CD)	М]A1
Code 93	L]G0	Standard Code 39(CDV & not send CD)]A3
Code 11(disable CDV)]H0	Interleaved 2 of 5(CDV & send CD)]I1
Code 11(send one CD)	т]H0	Interleaved 2 of 5(CDV & not send CD)	Ι]I3
Code 11(send two CD)	J]H1	Interleaved 2 of 5(disable CDV)]10
Code 11(not send CD)]H3	Databar		
Telepen(ASCII)	TT]B0	Databar Stacked	0	
Telepen(Numeric)	U]B1	Databar Stacked Omnidirectional	G	
IATA 2 of 5	R]R0	Databar Truncated]e0
Industrial 2 of 5	V]S0	Databar Limited	С	
China Post Code	Н]X0	Databar Expanded	0	
PDF417	Ζ]E0	Databar Expanded Stacked	V V	

SET ID - SETTING PROCEDURES

Setting steps:

- 1. Scan the SET ID bar code for a particular symbology.
- 2. Scan one or two alphanumeric characters from the Full ASCII Table.
- 3. Scan the SET ID bar code again.

```
Example: Define the MSI Code ID = A, Code 93 = G9

MSI :

Step1: Scan MSI Set ID (Group 9).

Step2: "A" from (Group 37).

Step3: Scan MSI Set ID (Group 9).

Code 93:

Step1: Scan Code 93 Set ID (Group8).

Step2: "G" from(Group37), Scan "9" from(Group41).

Step3: Scan Code 93 Set ID (Group8).
```

- The length of a Code ID is either one or two characters. If one character is set, the Code ID output will be one character. If two characters are set, the Code ID output will be two characters.
- 2. Only one type of Code ID will be sent.

CODE ID CONFIGURATION: SET ID

	EAN 13 Set ID
. P002\$	EAN 8 Set ID
. Poo3\$	UPC E Set ID
. P004\$	UPC A Set ID
. Poos\$	Code 39 Set ID
. Po 13\$	Code 93 Set ID
. P007\$	Codabar Set ID
. PD21\$	IATA Set ID
. Po 10\$	Code 128 Set ID
.Po16\$	EAN 128 Set ID
. PD22\$	Telepen Set ID
. Poo9\$	Code 11 Set ID
. Po11\$	Code 32 Set ID
. PO 1 2\$	China Post Code (TOSHIBA Code) Set ID

CODE ID CONFIGURATION: SET ID

MSI Code Set ID **UK Plessey Set ID** Matrix 2 of 5 Set ID Interleaved 2 of 5 Set ID Industrial 2 of 5 Set ID Full ASCII Code39 Set ID GS1 Databar (RSS) Limited Set ID GS1 Databar (RSS) Expanded Set ID GS1 Databar (RSS) Set ID LABEL Code Set ID (Reserved)







- The scanner will beep three times as a reminder that a setting is not yet complete.
- If you make a mistake, forget a step, etc., scan RESET to start again.

DELAY BETWEEN BLOCKS AND CHARACTERS

INTERBLOCK DELAY	
	<u>0mS</u>
. 8002\$	10mS
. 8003\$	50mS
. 8004\$	100mS
. 8005\$	200m\$
	500mS
INTERCHARACTER DELAY	
	<u>140uS</u>
. 80 1 1 \$	500uS
. 8012\$	1mS
. 8013\$	4mS

16mS

. BO14\$

KEYBOARD LAYOUT/ CAPLOCK MODE/ NUMERIC KEY





CO13\$



CAPITAL LOCK MODE







- When barcode scanner is set to Caplock Free mode, no matter keyboard Capslock LED indicator is ON or OFF, output will be always the same as the Original barcode. In other words, what you see is what output is.(CODABAR is the exception)
- If ABCD/ ABCD, abcd/ abcd, ABCD/T*E, abcd/tn*e are on, they work independently according to their rules.





RS232: BAUD RATE, DATA BITS & PARITY








RS232: STOP BIT, HANDSHAKING, ACK/NAK, FLOW CONTROL, BCC



37

WAND EMULATION PARAMETER SETTING





PEN TYPE

ENABLE/ DISABLE SYMBOLOGIES



DISABLE

















CODE 128





ENABLE/ DISABLE SYMBOLOGIES



DISABLE





UPC-E



















ENABLE/DISABLE SYMBOLOGIES, CHINA POSTAL CODE

ENABLE













DISABLE













CHINA POSTAL CODE [TOSHIBA CODE]















41

APPENDIX

FULL ASCII (Code 39) NUMERIC TABLE



SETTING PROCEDURE

MIN / MAX LENGTH

STEP 1 - Scan: MIN LENGTH/ MAX LENGTH STEP 2 - Scan: Two digits from Appendix. STEP 3 - Scan: MIN LENGTH/ MAX LENGTH

Please note that when Min Length and / or Max Length are enabled, the scanner will only read bar codes that fall into those length parameters. Bar codes shorter or longer than specified will not be read. The default lengths for these are indicated in parentheses under the Min and Max bar codes for each symbology.

- The scanner will beep three times as a reminder that a setting is not yet complete.
- 2. If you make a mistake, forget a step, etc., Scan RESET to start again.



SYMBOLOGIES: MSI CODE, UK PLESSEY CODE



MSI













UK PLESSEY CODE





APPENDIX

FULL ASCII (Code 39) NUMERIC TABLE



SETTING PROCEDURE

MIN / MAX LENGTH

STEP 1 - Scan: MIN LENGTH/ MAX LENGTH STEP 2 - Scan: Two digits from Appendix. STEP 3 - Scan: MIN LENGTH/ MAX LENGTH

Please note that when Min Length and / or Max Length are enabled, the scanner will only read bar codes that fall into those length parameters. Bar codes shorter or longer than specified will not be read. The default lengths for these are indicated in parentheses under the Min and Max bar codes for each symbology.

- The scanner will beep three times as a reminder that a setting is not yet complete.
- 2. If you make a mistake, forget a step, etc., Scan RESET to start again.



SYMBOLOGIES: CODE 93, TELEPEN, IATA



CODE 93







TELEPEN



TELEPEN ASCII







IATA







APPENDIX

FULL ASCII (Code 39) NUMERIC TABLE



SETTING PROCEDURE

MIN / MAX LENGTH

STEP 1 - Scan: MIN LENGTH/ MAX LENGTH STEP 2 - Scan: Two digits from Appendix. STEP 3 - Scan: MIN LENGTH/ MAX LENGTH

Please note that when Min Length and / or Max Length are enabled, the scanner will only read bar codes that fall into those length parameters. Bar codes shorter or longer than specified will not be read. The default lengths for these are indicated in parentheses under the Min and Max bar codes for each symbology.

- The scanner will beep three times as a reminder that a setting is not yet complete.
- 2. If you make a mistake, forget a step, etc., Scan RESET to start again.



SYMBOLOGIES: INTERLEAVED 2 OF 5, CODE 11







CODE 11





CDV & NOT SEND CD





APPENDIX

FULL ASCII (Code 39) NUMERIC TABLE



SETTING PROCEDURE

MIN / MAX LENGTH

STEP 1 - Scan: MIN LENGTH/ MAX LENGTH STEP 2 - Scan: Two digits from Appendix. STEP 3 - Scan: MIN LENGTH/ MAX LENGTH

Please note that when Min Length and / or Max Length are enabled, the scanner will only read bar codes that fall into those length parameters. Bar codes shorter or longer than specified will not be read. The default lengths for these are indicated in parentheses under the Min and Max bar codes for each symbology.

- The scanner will beep three times as a reminder that a setting is not yet complete.
- 2. If you make a mistake, forget a step, etc., Scan RESET to start again.



SYMBOLOGIES: INDUSTRIAL 2 OF 5, MATRIX 2 OF 5



INDUSTRIAL 2 OF 5















MATRIX 2 OF 5







APPENDIX

FULL ASCII (Code 39) NUMERIC TABLE



SETTING PROCEDURE

MIN / MAX LENGTH

STEP 1 - Scan: MIN LENGTH/ MAX LENGTH STEP 2 - Scan: Two digits from Appendix. STEP 3 - Scan: MIN LENGTH/ MAX LENGTH

Please note that when Min Length and / or Max Length are enabled, the scanner will only read bar codes that fall into those length parameters. Bar codes shorter or longer than specified will not be read. The default lengths for these are indicated in parentheses under the Min and Max bar codes for each symbology.

- The scanner will beep three times as a reminder that a setting is not yet complete.
- 2. If you make a mistake, forget a step, etc., Scan RESET to start again.



SYMBOLOGIES: CODABAR



CLSI- Enable library space insertion. If you enable the CLSI format, this option inserts spaces in position 2, 7, 13 of the data string for use in library systems.

CODABAR



MIN LENGTH (6)





51

APPENDIX

FULL ASCII (Code 39) NUMERIC TABLE



SETTING PROCEDURE

MIN / MAX LENGTH

STEP 1 - Scan: MIN LENGTH/ MAX LENGTH STEP 2 - Scan: Two digits from Appendix. STEP 3 - Scan: MIN LENGTH/ MAX LENGTH

Please note that when Min Length and / or Max Length are enabled, the scanner will only read bar codes that fall into those length parameters. Bar codes shorter or longer than specified will not be read. The default lengths for these are indicated in parentheses under the Min and Max bar codes for each symbology.

- The scanner will beep three times as a reminder that a setting is not yet complete.
- 2. If you make a mistake, forget a step, etc., Scan RESET to start again.



SYMBOLOGIES: ABC- CODABAR, CX- CODABAR



ABC- CODABAR





* The data can be any alphanumerics of FULL ASCII Table (GROUP 33-41)

REMARK:

SET INSERT DATA

ABC-CODABAR (American Blood Commission). The ABC Code is an acronym for American Blood Commission. This bar code is a variant of the CODABAR Code developed for the use in the blood bank. This Code consists of two bar codes which are decoded in one read cycle. The code is concatenated when the stop character of the first bar code and the start character of the second bar code is a "D", these two "D" are not transmitted.



CX CODE- CODABAR





* The data can be any alphanumerics of FULL ASCII Table (GROUP 33-41)

REMARK:

The CX-Code consists of two bar codes which are decoded in one read cycle, the code is concatenated when the stop character of the first bar code is a C, and the start character of the second bar code is a B. The B and C characters are not transmitted.

SYMBOLOGIES: CODABAR COUPLING, ADJACENT REQUIRED



SET INSERT DATA

CODABAR COUPLING





ABC-Codabar and CX-Codabar have certain rules regarding the Stop Character of first bar code and the stop character of second bar code while in conjunction, while Codabar-Coupling is enabled, the data from any two Codabar bar codes can be coupled into one set of data without any limitations between the Stop character of first bar code and the Start character of second bar code. The Start and Stop characters associated with each bar code will be sent.



ADJACENT REQUIRED

If CODABAR ADJACENT is enabled, the scanner will only read two adjacent Codabar bar codes; a single bar code will not be read.



NOTES:

- 1. Both ABC-Codabar and CX-Codabar can be enabled together, except when Codabar-Coupling is also enabled.
- If ABC-Codabar, CX-Codabar, and Codabar-Coupling are all enabled at the same time, the scanner will read only Codabar-Coupling, that is, ABC-Codabar, CX-Codabar will be considered coupling formats.

SETTING PROCEDURE - SET INSERT DATA

Step 1- Scan SET INSERT DATA.

- Step 2- Scan any combination of alphanumeric characters from FULL ASCII Table.
- Step 3- Scan SET INSERT DATA.



- The scanner will beep three times as a reminder that a setting is not yet complete.
- If you make a mistake, forget a step, etc., Scan RESET to start again.

SYMBOLOGIES: STANDARD & FULL ASCII CODE 39, CODE 32





DISABLE



ENABLE



DISABLE



START / STOP - SEND













NOTE:

The default for Code 39 is Standard Code 39. If Full ASCII Code 39 is enabled, Standard Code 39 will be automatically disabled.





CODE 32







APPENDIX

FULL ASCII (Code 39) NUMERIC TABLE



SETTING PROCEDURE

MIN / MAX LENGTH

STEP 1 - Scan: MIN LENGTH/ MAX LENGTH STEP 2 - Scan: Two digits from Appendix. STEP 3 - Scan: MIN LENGTH/ MAX LENGTH

Please note that when Min Length and / or Max Length are enabled, the scanner will only read bar codes that fall into those length parameters. Bar codes shorter or longer than specified will not be read. The default lengths for these are indicated in parentheses under the Min and Max bar codes for each symbology.

- The scanner will beep three times as a reminder that a setting is not yet complete.
- 2. If you make a mistake, forget a step, etc., Scan RESET to start again.



SYMBOLOGIES FORMATTING: UPC-E



NOTE:

If ADDENDA REQUIRED is set to ON, the scanner will only read an UPC-E bar code that has an addenda. At the same time please also scan +5 ON or +2 ON so the scanner will output a 5-digit or 2-digit addendum.

SYMBOLOGIES: UPC-E SYSTEM NUMBER





UPC-E1

UPC-EO





NOTE:

Most UPC bar codes lead with 0 number systems, for these bar codes use UPC E(0) selection. For the bar codes that lead with the 1 number, use UPC E(1) selection.

UPC-E EXPAND To UPC-A





- 1. If UPC-E EXPAND TO UPC A FORMAT is enabled, the output of UPC-A will be 12 digits.
- The default output of UPC-A is 12 digits, if UPC-A EXPAND TO EAN13 is enabled, a zero will be added to in front of the bar code.

SYMBOLOGIES FORMATTING: UPC- A



NOTE:

If ADDENDA REQUIRED is set to ON, the scanner will only read an UPC-E bar code that has an addenda. At the same time please also scan +5 ON or +2 ON so the scanner will output a 5-digit or 2-digit addendum.

59

SYMBOLOGIES FORMATTING: EAN 8



NOTE:

If ADDENDA REQUIRED is set to ON, the scanner will only read an UPC-E bar code that has an addenda. At the same time please also scan +5 ON or +2 ON so the scanner will output a 5-digit or 2-digit addendum.







NOTE:

Both ISSN and ISBN are the extension codes of EAN-13. If scanner is required to read either ISSN or ISBN, EAN-13 must be enabled. Otherwise the scanner will not be able to read ISSN or ISBN.





61

SYMBOLOGIES: EAN/UCC-128, CODE 128





NOTES: DEFINE EAN 128

The first FNC1 character is translated to]c1, and the second FNC1 character is translated to an ASCII <GS> character (scan from Group 41)

String format:

]C1	DATA CHARACTERS	<gs></gs>	DATA CHARACTERS

Setting Procedure:

1: Scan DEFINE EAN128. 2: Scan ASCII Code (Group 41) 3: Scan DEFINE EAN128.

5. Scall DEFINE EAIN128.













GS1 DataBar, LIMITED, EXPANDED GS1 DataBar (RSS) - OMNI & STACKED N032\$ N033\$ GS1 DataBar ENABLE NO34\$ GS1 DataBar DISABLE ND35\$ G\$1 DataBar CHECK DIGIT SEND ND36\$ GS1 DataBar CHECK DIGIT NOT SEND ND37\$ GS1 DataBar PREFIX SEND ND38\$ GS1 DataBar PREFIX NOT SEND GS1 DataBar STACKED ENABLE ND39\$ 0249 GS1 DataBar STACKED DISABLE GS1 DataBar SET ID GS1 DataBar (RSS) - LIMITED NO10\$ G\$1 DataBar LIMITED ENABLE ND12\$ GS1 DataBar LIMITED DISABLE 1013\$ GS1 DataBar LIMITED CHECK DIGIT SEND ND24\$ G\$1 DataBar LIMITED CHECK DIGIT NOT SEND G\$1 DataBar LIMITED PREFIX SEND 019± GS1 DataBar LIMITED PREFIX NOT SEND GS1 DataBar LIMITED SET ID GS1 DataBar (RSS) - EXPANDED ND26\$ NO27\$ GS1 DataBar EXPANDED ENABLE NO28\$ GS1 DataBar EXPANDED DISABLE ND29\$ GS1 DataBar EXPANDED STACKED ENABLE 030\$ DataBar EXPANDED STACKED DISABLE ND31\$ G\$1 DataBar EXPANDED MIN LENGTH 2020\$ GS1 DataBar EXPANDED MAX LENGTH GS1 DataBar EXPANDED SET ID

FULL ASCII TABLE (CODE 39) CONTROL CODES

	NUL
\$A 	SOH
\$B	STX
\$C	ETX
\$D	EOT
\$E 	ENQ
\$F	ACK
\$G	BEL
\$н 	BS
\$1 	HT
	LF
\$K 	VT
\$L 	FF
\$M 	CR
\$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$	SO
\$0 	SI

FULL ASCII TABLE (CODE 39) CONTROL CODES

DLE	\$P
DC1	\$R
DC2	
DC3	
DC4	
NAK	\$∪
SYN	\$V
ETB	\$W
CAN	\$×
EM	\$Y
SUB	\$Z
ESC	%A
FS	%в
GS	
RS	
US	%E
SP	

FULL ASCII TABLE (CODE 39) SYMBOLS

	+
	-
	•
\$ 	\$
	%
	/
	١
	!
	@
%N	#
%s	^
/ F	~
	&
%D	*
/////////////////////////////////////	-
%q	=

FULL ASCII TABLE (CODE 39) SYMBOLS

{	% P
}	%R
[%К
]	%м
(
)	
<	%G
>	%1
•	%₩
	/в
,	
,	
•	%F
:	
?	
DEL	%т

FULL ASCII TABLE (CODE 39) UPPER CASE ALPHABETS

	A
B	В
	С
	D
E 	E
	F
G 	G
	Н
	I
	J
к 	К
	L
M	М

FULL ASCII TABLE (CODE 39) UPPER CASE ALPHABETS

Ν	×
0	
Ρ	₽
Q	
R	R
S	S
T	
U	
V	
W	
Х	
Y	
Z	z

FULL ASCII TABLE (CODE 39) LOWER CASE ALPHABETS

	а
+ B 	b
+ c	с
+ P	d
+ E	е
+ F	f
+ G	g
+ #	h
	i
	j
+ĸ	k
+ L 	Ι
+ M	m

FULL ASCII TABLE (CODE 39) LOWER CASE ALPHABETS

n	+ x
0	+ 0
р	+P
q	+ Ģ
r	+ R
S	+s
t	+T
u	
v	+v
w	+ w
x	+ x
У	+ Y
z	+z

FULL ASCII TABLE (CODE 39) NUMBERS

1
2
з
4
5
6
7
8
9
GROUP-42

FULL ASCII TABLE (CODE 39) FUNCTION KEYS

F1	
F2	\$ТВ
F3	\$TC
F4	\$TD
F5	\$TE
Fó	\$TF
F7	\$TG
F8	\$TH
F9	\$T!
F10	\$⊤J
F11	\$тк
F12	\$TL
Home	\$TM
End	\$TN
Enter (Numeric Key)	\$T+D
Арр	\$т+о

GROUP-43

FULL ASCII TABLE (CODE 39) NAVIGATION KEYS

\$TO	Cursor Right
\$TP 	Cursor Left
\$⊤Q 	Cursor Up
\$TR	Cursor Down
\$TS	Page Up
₩ТТ 	Page Down
\$T∪ 	Tab
\$TV 	Back Tab
\$T₩ 	Esc
\$TX	Enter
\$TY 	BS
\$TZ	Ins
\$Т%К	Del

GROUP-44

FULL ASCII TABLE (CODE 39) MODIFIER KEYS



\$T%M















For UK Keyboard Special Character





Note:

*1: When "Alt(Left)Make" is programmed, please scan "Alt(Left)Break" to resume barcode setting. *2: When "Shift(Left)Make" is programmed, please scan "Shift(Left)Break" to resume barcode setting. *3: When "Ctrl(Left)Make" is programmed, please scan "Ctrl(Left)Break" to resume barcode setting.

75



Our Barcode Scanners are simple to install and use. Most operational issues can be attributed to:



INCORRECT INTERFACE CONNECTION INCORRECT CONFIGURATION SETUP POOR BARCODE QUALITY

GENERAL PROCEDURES

- First, make sure the scanner is firmly connected to the host computer, when attached correctly, the scanner will emit one long beep. When the trigger is pressed, LED will flash.
- 2. Once the power is on, try scanning some sample bar codes from this user's guide. The scanner should beep and the LED should flash to indicate a good read in the default configuration. If reading the bar code does not result in a good read, there may have been a problem with the scanning technique or the interface configuration setting. Reset the scanner to default.
- 3. If the scanner indicates a good read, but there is no output of data to the monitor, please check the cabling connection.

KEYBOARD INTERFACES PROBLEMS

In general, the Keyboard Wedge interface is trouble free, but there is still something to check in the event of a problem:

Do you have the correct cable?

Most computers use an XT/AT-compatible keyboard. Be sure you have the proper cable for your computer.

Does the keyboard work?

Since the keyed-in data from keyboard must pass through the decoder, the cabling connections are correct if the keyboard is functioning.

Can your computer accept the data fast enough?

Your computer's BIOS has a feature related to keyboard typing speed. Try to set the Intercharacter Delay feature to stimulate the keystroke entry speed.

Does keyboard port supply enough power?

Most notebook computers do not supply enough power to the scanner. The symptom of insufficient power is a lower "good read" rate (since there is not enough power to properly support the scanning operation).



Is the proper symbology enabled?

Each bar code symbology can be individually enabled or disabled. It is suggested that you enable only those that you will be scanning, thereby eliminating the possibility of mis reads from the scanning of other symbologies.

Does the selected bar code symbology configuration match the bar code(s) being read?

Scanned data from each bar code symbology can be restricted to eliminate the scanning of unused symbologies. The restrictions are individually set for each symbology.

POOR BAR CODE QUALITY

The third problem area has nothing to do with the scanner, but rather the printed quality of the bar code and/or the scanning technique employed.

TOLERANCE OF BAR CODE

A bar code may have a tolerance. Normally, the tolerances are caused by bar code font software or a printer. Software with a proven reputation should be chosen to generate bar codes. If the printed bar codes are distorted, the scanner might not recognize them.

It is very difficult to get a good read from a poor quality bar code unless it is scanned many times. As the quality of the symbology drops, the chances for undetected error increase. A bar code Check Digit Verification (CDV) should be used to check the quality of the suspect bar codes.

LABELS (PAPER & COLOR & PRINTER)

The light source of a bar code scanner is generally red, so there are some restrictions for the printing of labels. Care should be taken when choosing materials, especially color inks and papers. Sometimes the combination of the label color and the color of the ink can, in effect, blind the scanner. Media with a shiny surface will also cause reading difficulties for scanners.

Moreover, poor printing quality can also result in reading difficulties for the scanner. Bad printing may be caused by the type of printer used; dot matrix and inkjet printers will not procedure high quality bar codes. Also check to make sure the ink, ribbon, or toner in good supply.



Is the proper symbology enabled?

Each bar code symbology can be individually enabled or disabled. It is suggested that you enable only those that you will be scanning, thereby eliminating the possibility of mis reads from the scanning of other symbologies.

Does the selected bar code symbology configuration match the bar code(s) being read?

Scanned data from each bar code symbology can be restricted to eliminate the scanning of unused symbologies. The restrictions are individually set for each symbology.

POOR BAR CODE QUALITY

The third problem area has nothing to do with the scanner, but rather the printed quality of the bar code and/or the scanning technique employed.

TOLERANCE OF BAR CODE

A bar code may have a tolerance. Normally, the tolerances are caused by bar code font software or a printer. Software with a proven reputation should be chosen to generate bar codes. If the printed bar codes are distorted, the scanner might not recognize them.

It is very difficult to get a good read from a poor quality bar code unless it is scanned many times. As the quality of the symbology drops, the chances for undetected error increase. A bar code Check Digit Verification (CDV) should be used to check the quality of the suspect bar codes.

LABELS (PAPER & COLOR & PRINTER)

The light source of a bar code scanner is generally red, so there are some restrictions for the printing of labels. Care should be taken when choosing materials, especially color inks and papers. Sometimes the combination of the label color and the color of the ink can, in effect, blind the scanner. Media with a shiny surface will also cause reading difficulties for scanners.

Moreover, poor printing quality can also result in reading difficulties for the scanner. Bad printing may be caused by the type of printer used; dot matrix and inkjet printers will not procedure high quality bar codes. Also check to make sure the ink, ribbon, or toner in good supply.

APPENDIX 1 DEFAULT TABLE 1

GROUP	PARAMETER	DEFAULT
	Computer Type	PC-AT
1	Interface	(depends on customer order)
	Setup Code	On
2	Reading Mode	Trigger
2.2	Bi-color Light Source	Green > Red
	Magnetic Switch	On
2.3	Green LED/ Supplement Light (CCD Scanner)	On
	Deactivation Time (CCD & Laser Scanner)	3 Sec
	Same Code Interval (Laser Scanner)	30 Sec
2.4	Idla Mode	Off
	Dra Idla Tima	1.1.6
2.6		1 Min
2.6	Connection Options	BTHID
2.8	Wireless ID	Wireless Scanner
2.9	Power Off Timeout	3 Min
2.10	SSP (Secure Simple Pairing)	Disable
	iOS Hotkey	Disable
2.11	Link Quality	Disable
	Batch Mode	Disable
2.13	SPP Pincode	1234
2.15	Memory Mode	Disable
	Data Output Method	Wireless
2.16	Data Format	<item no.=""><date><time><barcode data=""></barcode></time></date></item>
2.10	Field Separator	,
2.17	Date Format	DD/MM/YYYY
2.17	Time Format	HH:MM:SS
	Beep Tone Mode 2.1k	Beep Medium
3	Beep Tone Mode 2.7k	Beep Medium
	Terminator	CR(KB, USB); CR+LF(RS232)
4	Send Data Length	Off
-	Preamble & Postamble	None
5	Accuracy Adjustment	0
6	Label Type Positive/ Negative	Disable
6~9	Enable & Disable Code ID	Off
10	Intercharacter Delay	140us
	Keyboard Layout	English(USA)
11	Caplock	Off
	Numeric Key	Alphanumeric Key
12	Baud Rate	9600
12	Data Bits & Parity	8 Bits None
	Stop Bits	1 stop bit
	Handshaking	None
13	ACK/NAK	Off
	Flow Control Timeout	1 Sec
	BCC	Off
	Level duration of Mini width	200us
14	Polarity of Idle Condition	High Bos High/ Space Low
	Wave Form	Full ASCII 39
	Idle Mode	Off
	Pre-Idle Time	1 Min
	Enable and Disable Symbologies	
	Code 32	Disable
	China Postal Code	Enable
	UK Plessey Code	Disable
15	Industrial 2 of 5	Disable
15	Matrix 2 of 5	Disable
	Interleaved 2 of 5	Enable
	Code 128	Enable
	Codabar	Enable
	Telepen	Disable



DEFAULT TABLE 2

GROUP		PARAMETER	DEFAULT	
		UPC-A	Enable	
		UPC-E	Enable	
		EAN-8	Enable	
		EAN-13	Enable	
16		MSI	Disable	
		Code 39	Enable	
		Code 11	Disable	
		Code 93	Disable	
		EAN-128	Enable	
		IATA	Disable	
		GS1 Databar	Disable	
		GS1 Databar Stacked	Enable	
	1	GS1 Databar Limited	Disable	
		GS1 Databar Expanded	Disable	
		GS1 Databar Expanded Stacked	Enable	
17		PDF417	Disable	
		China Post Code		
		Enable/Disable	Enable	
	2	Check Digits	Disable CDV	
		Min Length	11 digits	
		Max Length	48 digits	
		MSI		
	1	Enable/Disable	Disable	
	1	Check Digits	CDV & send CD	
18		Check Digits Mode	Single MOD 10	
		UK Plesssy		
	2	Enable/Disable	Disable	
		Check Digits	CDV & not send CD	
		Code 93		
	1	Enable/Disable	Disable	
		Min Length	6 digits	
		Max Length 48 digits		
	2	Feeble/Dioskle	Disable	
19		Telepen A SCII/ Number	Number	
		IATA	rumoer	
		Enable/Disable	Disable	
	3	Check Digits	Disable CDV	
	-	Min Length	6 digits	
		Max Length	48 digits	
		Interleaved 2 of 5		
		Enable/Disable	Enable	
	1	Check Digits	Disable CDV	
		First/ last digit suppressed	No suppressed	
		Min Length	6 digits	
20		Max Length	48 digits	
		Code II		
		Enable/Disable	Disable	
	2	Check Digits	Disable CDV	
		Min Length	6 digits	
		Max Length	32 digits	
		Enable/Disable	Disable	
	1	Check Digits	Disable CDV	
		Min Length	6 digits	
		Max Length	48 digits	
21		Matrix 2 of 5	10 alguo	
		Enable/Disable	Disable	
	2	Check Digits	Disable CDV	
	.	Min Length	6 digits	
		Max Length	48 digits	

DEFAULT TABLE 3

GROUP		PARAMETER	DEFAULT
		Codabar	
		Enable/Disable	Enable
		Check Digits	Disable CDV
		Min Length	6 digits
22		Max Length	48 digits
		ST/SP; Abcd/abcd, abcd/tn*c, ABCD/ABCD,ABCD/TN*C	ABCD/ABCD
		Start(ST)/Stop(SP)	Send
		CLSI Format	On
		ABC-Codabar	
	1	ON/OFF	Off
23		Insert Data	Off
	2	CA-Codabar	Off
	-	Insert Data	Off
		Codabar-Coupling	0.1
24		ON/OFF	Off
24		Insert Data	Off
		Adjacent Required	Off
		Code 39	
		Full ASCII 39 Enable/Disable	Enable
	1	Check Digits	Disable CDV
		Start/Stop	Not Send
25		Min Length	I digit
		Max Length	48 digits
		Code 32	Dissibility
	2	Enable/Disable	Disable
		Tailing	send
		UPC-E	send
		Enable/Disable	Enable
		Check Digits	Send
		Lead Digits	Send
26		Add a space	Off
		Addenda required	Off
		+5 On/Off	Off
		+2 On/Off	Off
		UPC-E systems number	
		UPC E(0) On/Off	On
27		UPC E(1) On/Off	Off
		UPC-E expand to UPC-A	Disable
		UPC-A expand to EAN-13	Disable
		UPC-A	
		Enable/Disable	Enable
		Check Digits	Send
28		Lead Digits	Send
		Add a space	Off
		Addenda required	Off
		+5 On/Off	Off
		+2 On/Off	Off
		EAN-8	
		Enable/Disable	Enable
		Check Digits	Send
		Lead Digits	Send
29		Add a space	Off
		Addenda required	Off
		+5 On/Off	Off
		+2 On/Off	Off

APPENDIX 1 DEFAULT TABLE 4

GROUP		PARAMETER	DEFAULT	
		EAN-13		
		Enable/Disable	Enable	
		Check Digits	Send	
		Lead Digits	Send	
20		Add a space	Off	
50		Addenda required	Off	
		+5 On/Off	Off	
		+2 On/Off	Off	
		ISSN On/Off	Off	
		ISBN	Off	
		EAN/UCC128		
		Enable/Disable	Enable	
	1	Code ID	Disable	
		Func 1 Char Send	Not Send	
	2	Code 128		
31		Enable/Disable	Enable	
		Check Digits	Disable CDV	
		Min Length	5 digits	
		Max Length	48 digits	
	3	PDF417		
	2	Enable/Disable	Disable	
32		GS1 Databar	Disable	
		GS1 Databar Check Digit	Not Send	
		GS1 Databar Prefix	Not Send	
		GS1 Databar Stacked	Enable	
		GS1 Databar Limited	Disable	
		GS1 Databar Limited Check Digit	Not Send	
		GS1 Databar Limited Prefix	Not Send	
		GS1 Databar Expanded	Disable	
		GS1 Databar Expanded Stacked	Enable	

Cable Pin Assignment INTERFACES:

1. TTL, Wand Emulation

1.1) AMP (D-Sub 9Pin):



1.2) Din 5 male (240 degree):

Pin	Signal
1	+ 5VCC
2	Data
3	GND
4	N/A
5	N/A



2. Keyboard Interface:

Type of connector: 2.1) PS/2 Mini Din6 Female:





2.2) PS/2 Mini Din6 Male:





Type of connector:

2.3) PC-AT: Din 5 Male:

Pin	Signal
1	KB-Clk
2	KB-Data
3	NC
4	GND
5	+5VCC



2.4) PC-AT: Din 5 Female:



3.RS232 Interfaces:

3.1) DB9F





3.2) DB25F

Pin	Signal
2	RXD(In)
3	TXD(Out)
4	CTS(In)
5	RTS(Out)
7	GND
16	+5VCC
25	+5VCC



BAR CODE TEST CHART

DENSITY	NARROW	WIDE	CHAR.GAP	n/w
	mm(mil)	mm(mil)	mm(mil)	Ratio
MEDIUM DENSITY	0.25(10)	0.625(25)	0.25(10)	1/2.5

MEDIUM DENSITY

NW-7 (CODABAR)



CODE-39



CODE-39 TEST

Interleaved 2of5



UPC





EAN

BAR CODE TEST CHART

DENSITY	NARROW	WIDE	CHAR.GAP	N/W
	mm(mil)	mm(mil)	mm(mil)	Ratio
LOW DENSITY	0.33(13)	0.825(32.5)	0.33(13)	1/2.5

LOW DENSITY



C9876543210D



CODE-39 TEST



0012345690



